

Compatible Makita Tool Models

The Makita 643650-4 Brush Holder Cap is compatible with the following tools:

1002BA 4-3/8" Curved Base Planer
Makita 1806B 6-3/4" Planer
Makita 2012NB 12" Portable Planer
Makita 2705 / 2705X1 10" Table Saw
Makita 2703 / 2703X1 / 2704 / 2704X1 / 2702 / 2708 / 2711 Table Saws
Makita 5007F / 5007FA / 5007MG / 5007MGA / 5007NB / 5007N / 5007NK / 5007NBA / 5007NBK / 5007S / 5007FAK / 5007FK Circular Saws
Makita 5008FA / 5008MGA / 5008NB Circular Saws
Makita 5012B Electric Chain Saw
Makita 5014NB / 5016NB Chain Saws
Makita 5037NBA Circular Saw
Makita 5057KB Circular Saw with Dust Collector
Makita 5077B / 5277B / 5277NB / 5377MG / 5477NB Hypoid Saws
Makita 5201NA / 5402A Circular Saws
Makita 7104L Chain Mortiser
Makita GA7001L Angle Grinder
Makita GA7911 Angle Sander
Makita 9000BL / 9105 / 9607NB Type 1 & 2 / 9609B Grinders
Makita 9401 Belt Sander
Makita 4110C Angle Cutter
Makita 3601B / 3600H / 3612B / 3612BR / 3612BRA Routers
Makita 3803A Groove Cutter
Makita 6910 / TW1000 Impact Wrenches
Makita HM1211B / HM1242C / HM1301 Demolition Hammers
Makita HR5000 / HR5000K Type 1-4 / HR5001C / HR4500C Rotary Hammers
Makita UC3530 / UC3530A / UC3551A 14" Electric Chain Saws
Makita UC4030 / UC4030A / UC4051A 16" Electric Chain Saws
Makita ES-173A / ES-174 Electric Chain Saws
Makita 1804N / 1805N / 2004 / 2040 / 2040-2 Electric Planers
Makita 2012 / 2030 Type 1 / 2030N / 2040 Planer Jointers
Makita LS1000 / LS1011 / LS1011N / LS1013 / LS1013F / LS1013FL / LS1013L / LS1013 Type 3 & 4
Makita LS1016 / LS1016L / LS1016LX / LS1016LX5
Makita LS1019L / LS1019LX
Makita LS1020 / LS1030 / LS1040 / LS1040F
Makita LS1212 / LS1214FL / LS1214L / LS1216L / LS1216LX / LS1216LX4
Makita LS1219L / LS1219LX
Makita LS1221 / LS1400
Makita 2401B 10" Miter Saw

Always reference your tool's parts diagram to confirm compatibility before ordering.