Compatible with following Products:

FITS THE FOLLOWING PRODUCTS:

BLACK & DECKER:

BDSA100 4" Belt/6" Disc Sander

BDTS100 Type 1 Table Saw

SM300 Type 1 10 Drill Press

CRAFTSMAN:

0LVW

137215360 4 X 36" Sander

137217100 Router

137218040 Table Saw

137218041 Table Saw

137218100 Table Saw

137218101 Circular Saw

137218250 Table Saw

137218740 10" Table Saw

137218760 10" Table Saw

137218780 Table Saw

137219080 8" Drill Press

137221940 Table Saw

137221960 Table Saw

137228010 Table Saw

137228210 Table Saw

137229150 15" Drill Press

137229170 17" Drill Press

137229200 20" Drill Press

137229340 34" Drill Press

137248080 8" Drill Press

137248100 Table Saw

137248101 Circular Saw

137248250 Table Saw

137248740 10" Table Saw

137248760 10" Table Saw

137271060 10" Table Saw

137271070 Table Saw

137271140 Table Saw

137271160 10" Table Saw

137271180 Table Saw

137272070 10" Table Saw

137272210 Table Saw

137272220 Table Saw

137273350 15" Drill Press

137273370 17" Drill Press

137273380 20" Drill Press

137280050 8" Drill Press

137280680 8" Drill Press

137283290 4 X 36" Sander

137287100 Router

DELTA / ROCKWELL:

11-900 Type 1 Drill Press

11-900 Type 2 Drill Press

11-950 Type 1 Drill Press

11-950 Type 2 Drill Press

11-950 Type 3 Drill Press

11-980 Type 1 Drill Press

11-985 Type 1 Drill Press

11-990 Type 1 Drill Press

11-990 Type 2 Drill Press

11-990 Type 3 Drill Press

14-040 Type 1 Drill Press

14-070 Type 1 14" Drill Press

14-600 Type 1 Mortiser

14-650 Type 1 Mortiser

14-650 Type 2 Mortiser

17-900 Type 1 16-1/2" Drill Press

17-900 Type 2 16-1/2" Drill Press

17-950L 16-1/2" Drill Press

22-540 Type 1 12 inch Planer

22-540 Type 2 Planer

22-560 Type 1 Planer

22-560 Type 2 Planer

22-565 Type 1 Planer

23-655 Type 1 Grinder/Shapener

23-675 Type 1 Grinder / Finisher

28-150 Type 1 Band Saw

28-150 Type 2 Band Saw

28-160 Type 1 Band Saw

28-180 Type 1 8" Band Saw

28-185 Type 1 Band Saw

28-190 Type 1 Band Saw

28-195 Type 1 Band Saw

28-560 Band Saw

31-120 Type 1 Sander

31-120 Type 2 Sander

31-205 Type 1 8" Table Saw

31-325 Type 1 Grinder/Sander

31-340 Type 1 Sander

31-340 Type 2 Sander

31-340 Type 3 Sander

31-460 Type 1 Disc Sander

31-460 Type 2 Disc Sander

31-460 Type 3 Disc Sander

31-695 Type 1 Sander

31-695 Type 2 Sander

31-750 Type 1 Sander

31-780 Type 1 Sander

31-780 Type 2 Sander

33-990 Type 1 Radial Arm Saw

34-330 8-1/4" Builders Saw

34-570 Type 1 Table Saw

34-580 Type 1 9" Table Saw

34-670 Type 1 10 Inch Table Saw

34-670 Type 2 10 Inch Table Saw

34-695 Type 1 10" Table Saw

34-710 Type 1 Super 10 Saw

34-740 Type 1 Super 10 Saw

34-740 Type 2 Super 10 Saw

36-380 Type 1 Xl-10 Table Saw

36-546 Type 1 10" Bench Saw

36-600 Type 1 Table Saw

36-600 Type 2 Table Saw

HITACHI:

972-082Z

CB75F Band Saw

F-1000A

Planer Jointer

P100F Planer

P12RA 12-9/32" Planer/Jointer

SR15 Universal Saw

HUSKY:

THD950L

THD750L

PORTER CABLE:

887045

552 Type 1 Cutter

552 Type 2 Cutter

697 Router Table

698 Router Table

RIDGID:

1550015

RYOBI:

AP-12 Planer

BTS10 10" Table Saw

BTS12S 10" Table Saw

BTS10S Table Saw

DP101 10" Drill Press

89015001705

80015001640

452020007

4550031

16102010B